



- Installation instructions -

Brake fluid reservoir

– F 900 R/XR from Modell 2020 –



Part number: S700399-F15

General notes!



AC Schnitzer – F 900 R/XR from Modell 2020-

Important notes!

It is essential to read these installation instructions **before** starting installation work. AC Schnitzer accepts no liability for damage caused by improper installation!

These installation instructions are intended exclusively for use by authorised AC Schnitzer or BMW dealers. The target group for these installation instructions is always specialist personnel trained on BMW vehicles with the appropriate specialist knowledge and tools. Knowledge regarding material properties and standards is assumed!

Mounting

All work must be carried out in accordance with the applicable safety regulations (e.g. protective goggles).

Paint

n/a

Installation time (1 AW = 5 minutes)

The installation time is approx. **3 AW**, which may vary depending on the condition and equipment of the vehicle.

Paint (1 AW = 5 minutes)

n/a

Required tools

- Torx spanner
- Screwdriver
- Hexagon socket spanner
- Cleaning agent

Assembly instruction number: S700399-F15 / Stood: 10.11.2020

AC Schnitzer - Motorradtechnik - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135

Delivered components



AC Schnitzer



Assembly instruction number: S700399-F15 / Stood: 10.11.2020

AC Schnitzer - Motorradtechnik - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135

Installation instructions



AC Schnitzer

Park the vehicle safely with a motorbike stand with a motorcycle stand.



Loosen screw of the standard container.



Attach the enclosed holder with the O-rings, screws and washers to the AC Schnitzer Brake fluid reservoir (see picture).



Tightening torque: 2 Nm



Assembly instruction number: S700399-F15 / Stood: 10.11.2020

AC Schnitzer - Motorradtechnik - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135

Installation instructions



AC Schnitzer

Use suitable material to protect the vehicle from
Protect leaking liquid.


Using flat-nose pliers or a screwdriver, loosen the
release the safety clip on the container and
the reservoir from the hose in such a way that no liquid
can escape from the hose or the reservoir.

Place the original container upside down on a
clean work surface.

Slide the enclosed safety clip onto the original hose.

Push the original brake fluid hose onto the reservoir
connection fix it with the safety clip.

If necessary, press the clamp together a little to
to achieve more pretension.



Installation instructions



AC Schnitzer

Attach the holder to the frame with the original screws.

The nozzle of the container can be twisted in the process.

Twist off the cover and remove the membrane.

Make sure that the sight glass is in the viewing area,

If necessary, loosen the fastening screws and twist.

The hose must not be kinked.



Fill the new container.



Squeeze the hose several times to make sure that there are no air bubbles in the hose.



Close the container with the membrane and lid.

Check the complete brake system for function and Check tightness.



Assembly instruction number: S700399-F15 / Stood: 10.11.2020

AC Schnitzer - Motorradtechnik - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135