



-Fitting Instructions-

Lamp Mask BMW R nineT



Part No. S50121456703

General Notes!



AC Schnitzer Lamp Mask BMW R nineT

Important Notes!

Important Notes!

These Fitting Instructions must be read carefully before starting work, and do not claim to be complete in relation to every work step. Technical, editorial and content changes are reserved!! AC Schnitzer bears no liability for damage caused by incorrect installation!

Check goods for completeness and absence of damage before starting work.

Later complaints cannot be accepted.

These Fitting Instructions are intended solely for use by authorised AC Schnitzer or BMW dealers. These Fitting Instructions are in all cases directed at professionals trained in BMW vehicles who have the corresponding specialist knowledge and tools. Knowledge concerning material properties and standards is assumed! Work on electrical systems should only be carried out by trained personnel.

Before installation:

For installation, protect the vehicle adequately against rolling away or falling over.

We recommend the use of the normal main stand or an original BMW assembly stand! Keep children and animals away from the working area!

There is a risk of accident from tripping or electrical short-circuit! Therefore remove all jewellery (chains, watches, rings etc.) before starting work.

After installation:

After completion of the work, carry out a test ride. After the test ride, check all bolt connections for tightness and ensure that all moving parts have adequate clearance.

Fitting time: (1 unit = 5 minutes)

The fitting time is around 12 units, which may vary depending on vehicle condition and equipment level.
(This value is a recommendation only and is not binding!)

Painting time: (1 unit = 5 Minutes)

The painting time is around 12 units.

When painting, please ensure that the type approval number is NOT painted over.

Before painting, trial fit component, make any adjustments required, and then paint.

Tools Required

- Standard automotive Torx & socket drivers
- Thread lock (medium strength)

Contents




AC Schnitzer Lamp Mask BMW R nineT

Chapter	Page
1. Components supplied	4 □
2. Fitting the AC Schnitzer component	6

Components Supplied



AC Schnitzer Lamp Mask BMW R nineT



- A = AC Schnitzer lamp mask
- B = AC Schnitzer headlamp insert
- C = AC Schnitzer base holder 1
- D = AC Schnitzer base holder 2 & 3
- E = AC Schnitzer headlamp ring

Fitting Instructions No.: S50121456703/ Issue: 07 / 2015 RVo

AC Schnitzer - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135 / www.ac-schnitzer.de

Components Supplied



AC Schnitzer Lamp Mask BMW R nineT



- F = AC Schnitzer upright clamp set
- G = AC Schnitzer headlamp ring retaining clip set
- H = Rubber moulding ring for parking light fixing
- I = Headlamp fixing screw set
- J = Screw fitting kit (not shown)

Fitting Instructions No.: S50121456703/ Issue: 07 / 2015 RVo

AC Schnitzer - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -300 Fax -135 / www.ac-schnitzer.de

Fitting Instructions




AC Schnitzer Lamp Mask BMW R nineT

2. Fitting


- Park vehicle securely and protect against falling or rolling away. (Fig. 1)
- Before painting, fit component completely so any adjustments can be made.



- Remove standard headlamp unit by releasing the fixing screw and tipping the headlamp unit towards the front. (Fig. 2)



- Detach standard wiring harness from light unit (2). (Fig. 3)



Fitting Instructions



AC Schnitzer Lamp Mask BMW R nineT

2. Fitting


- On the standard wiring harness, remove the tension relief and push the rubber sleeve back out of the rear housing. (Fig. 4)



- Unthread the standard wiring harness with plugs towards the back through the exposed hole. (Fig. 5)



- Release and remove the standard fixing bolts of the headlamp housing, counter-holding the headlamp housing.
- Remove headlamp housing from vehicle. (Fig. 6)




Fitting Instructions




AC Schnitzer Lamp Mask BMW R nineT

2. Fitting

- Remove standard light unit by releasing the bracket from the catch and folding aside. (Fig. 7)



- Insert light unit in the AC Schnitzer headlamp supplied, ensuring it is correctly positioned, and securely attach the catch. (Fig. 8)
- Be careful not to touch the glass bulb of the light unit with your fingers at any time!



- Fit the AC Schnitzer headlamp ring supplied on the headlamp unit insert as shown, ensuring it is correctly positioned. (Fig. 9)




Fitting Instructions


AC Schnitzer Lamp Mask BMW R nineT

2. Fitting

- Using the retaining clips (5x) supplied, attach the headlamp ring to the headlamp insert.
- Push the rubber cover supplied onto the headlamp insert, ensuring it is correctly positioned: TOP = top (Fig. 10)



- Screw the base holder -1- onto the lamp mask with both screws as shown. On the inside, fit the screws with the washers and self-locking nuts supplied, align and tighten. (Fig. 11)



- Loosely attach the upright clamps supplied to the upright as shown.
- Ensure that the fixing bolts are accessible from the outside. (Fig. 12)




Fitting Instructions




AC Schnitzer Lamp Mask BMW R nineT

2. Fitting


- Provisionally fit the holding brackets (2&3) supplied to the upright clamp.
- On the standard handlebar as shown, when using AC Schnitzer clip-on handlebars and AC Schnitzer fork bridge, apply from the top as required.
- In all cases, ensure that the contact surface lies on the inside at the hole in the lamp mask.
- If necessary, adjust height of clamping ring and bend holding brackets slightly. (Fig.13)



- Attach the prepared lamp mask to the vehicle using the standard bolts. Place headlamp adjuster in centre position, and tighten both bolts together. (Fig. 14)



- Thread light unit plugs through the hole in the lamp mask, and securely close the hole with the cable grommet (Fig.15).




Fitting Instructions




AC Schnitzer Lamp Mask BMW R nineT

2. Fitting

- Isolate any visible wiring as required.
 - There is no need to extend the wiring harness.
- (Fig. 16)



- Insert side fixing bolts with countersunk washers through the lamp mask and holder, and loosely secure with the washers and screws supplied.
- (Fig. 17)



- Roll the rubber ring supplied onto the standard parking light holder. (Fig. 18)




Fitting Instructions




AC Schnitzer Lamp Mask BMW R nineT

2. Fitting

- Push plug onto light unit, ensuring that all plug contacts are securely engaged. (Fig. 19)



- Insert parking light holder in the hole provided in the headlamp, ensuring that the rubber ring engages behind the edge. (Fig. 20)



- Place headlamp on lamp mask and fasten as shown using the screws supplied.
- First coat screws lightly with thread lock.
- Carry out a function test on the lights.
- Check headlamp setting with adjustment gauge, correct if necessary, then tighten all bolts and check for firm seat.
- This component must be registered!

